

Addendum

CB Radio

2006 Cheetah



The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.

© Monaco Coach Corporation. All rights reserved. Safari® is a registered trademark of Monaco Coach Corporation. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.

The Citizen Band (CB) Radio is **NOT** offered as an option on the 2006 Cheetah; however, the motorhome is prewired for a CB Radio and that information still applies.


Disregard the following information on the Citizen Band Radio (Optional) published in the 2006 Cheetah Owner's Manual, **Section 5 – Equipment** on page 152.

CITIZEN BAND (CB) RADIO (Optional)

The CB radio is a low-powered transmitting device used for two-way, short-distance communications. The CB can be a very useful tool for emergency weather condition information and potential road hazards reported by other CB operators.

Handset:

- **Volume/On/Off** control has no effect on radio transmission.
- Squelch control is first turned up to a point where static or background noise can be heard then reduced to a point where the static disappears.
- The Channel Selector is used to select channels (1-40) by pressing the Channel **Up/Down** Tuning buttons.
- When the microphone button is pressed, the CB radio switches from a listening device to a transmitter. Anything spoken into the microphone is transmitted over the airway of the channel selected. Press the button to talk and release the button to receive a reply.



031147

Emergency Communication:

- Set the CB radio to Channel 9.
- Request a React base (if available) to respond by saying “Break Channel 9 for a React base” and provide the CB Distress Data (called **CLIP**) repeatedly so the nearest monitor may be of assistance:

Call sign - Identify yourself and vehicle.

Location - Be exact.

Injuries - How many? What type? Are persons trapped?

Problem - Give details and be specific about the assistance needed.

NOTE:

Channel 9 is for emergency use only.

Following rules of use:

Limit communication to five minutes at a time. Give others a chance to use the channel. **DO NOT** use illegally amplified transmitter power or illegally high antennas or promote illegal activities. **DO NOT** transmit profanity or music over the airway. **DO NOT** use the CB to sell merchandise or a professional service.

Troubleshooting:

- **Limited Range:** Weather conditions, environment, terrain, trees, other vehicles, and/or the power of the radio and its antenna, and matching of the Standing Wave Ratio (SWR) setting affect CB radio range. See the OEM (Original Equipment Manufacturer) manual to adjust SWR.
- **No Power:** Check the 5 Amp fuse in the front electrical bay on the roadside.



MONACO®

Monaco Coach Corporation

91320 Coburg Industrial Way

Coburg, OR 97408

800-634-0855

www.monaco-online.com

Warranty/Technical Support

Toll Free 877-466-6226

